

### INTRODUCTION

The CAPXLV2TK and CAPXLV2TKHD Back Box and Trim Kit allows you to flush mount a CAPXLV2 unit into a cutout of a wall (or other flat surface).

**Carton Inventory:** Back Box Assembly, Trim Plate, Instructions.

**Additional Items You May Need:** Rubber Mallet



**WARNING:** This product can expose you to chemicals including lead, which are known to the State of California to cause cancer or birth defects or other reproductive harm. For more information go to [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).

### INSTALLATION

1. Cut a hole in the wall to accommodate the back box of the trim kit (back box dimensions: 12-3/16" x 17-3/8" [31.0 cm x 44.1 cm]).
2. Place the back box into the cutout. Use metal shims or hold the box level while marking the mounting holes through the rear surface.
3. Use rubber mallet to snap the trim plate onto the back box ensuring the slots in trim plate are fully seated over the back box pins. (Be careful when using mallet to not dent or scratch trim plate finish)
4. Remove mounting knockouts found on the rear face of the CAPXLV2.
5. Install the CAPXLV2 inside the back box and fasten unit to surface.

